

HOW TO CHECK GPS CHART PLOTTER VERSION

1. Check the serial no. of your GPS Chart Plotter
2. If after the model, there is a number 2, then the unit is MKII. Other wise it is MKI.

Example: KP-708:



NOTE:

- KP-38S, KP-38, KP-38A, KP-39, KP-39A and KP-1299X are all **MKII**.
- MKI **CANNOT** use MKII Update
- MKI **CANNOT** use K-Chart 3.0 Map
- MKI **CANNOT** use Navionics+